


Impact of CMP/Cleaning Consumables on IC Device Yield and CoO

Raymond R. Jin, Jerry Diao, Franklin Xu

Adcon Lab Incorporated



6110 Running Springs Road, San Jose, CA 95135 USA
(408)531-9187 (office), (408)623-6808 (cell), (408)532-8886 (fax)
www.adconlab.com, Raymond_Adcon@adconlab.com (e-mail)

How to Identify Yield Killer Defects?



Consumable manufacturer + solution provider + IC fab partner = High ROI

Benchmark CoO of Legacy Ceria STI CMP in Advanced IC Production Fabs




- Yield loss attributed to CMP defects
- CMP/Cleaning Consumables/WFE/Labors/Management

Copyright © Adcon Lab Inc., All rights reserved.

**CMP-defect-induced yield loss attributes to >50% CoO
at legacy ceria STI CMP**

Benchmark of IC Yield Loss due to the Defects Generated during Legacy Ceria STI CMP




- Large and/or irregular-shaped rigid abrasive particulates induced defects during CMP
- Other CMP defects

Copyright © Adcon Lab Inc., All rights reserved.


Yield loss at legacy ceria STI CMP is attributed mainly to scratches, large and irregular shaped ceria particles

What Abrasive Particle is Desirable for Minimizing and Eliminating Defects?



NanoCeria™ CMP solution is desirable for eliminating yield-killer defects


Reduction of Direct STI CMP Defects and μ -Scratches by Adcon NanoCeria™ Slurry



NanoCeria™ based slurry reduces STI CMP defects and μ -scratches by >40%


TEM Copyright © Adcon Lab Inc., All rights reserved.

Impact of Cleaning Consumable on IC Yield



CY18™ cleaning solution improves IC device yield by 30% in production fabs

Defect Performance at a Production Fab



NanoSilica™ & NanoCeria™ CMP solution improves defect performance and reduces CMP CoO by >50% over a >3000-wafer continued production run

Summary

- CMP-defect-induced yield loss attributes to >50% CoO at legacy ceria STI CMP at advanced tech nodes and the yield loss is attributed mainly to scratches, large and irregular shaped ceria particles
- Advanced consumable technologies (such as NanoCeria™ CMP solution and CY18™ cleaning solution) are promising with desired fab/supplier partnership in improving IC yield and reducing CoO for critical process modules (including direct STI CMP) at advanced tech nodes
- Low cost by design in a global consumable supply food-chain is effective in significantly reducing CMP CoO